



*Fuel water separator 75/1000FHX
EF-11001*



*Fuel water separator 75/900FHX
EF-11002*



*Fuel water separator 75/500FGX
EF-11003*



*Fuel water separator 1000FH
EF-11004*



*Fuel water separator 1000FG
EF-11005*



*Fuel water separator 900FH
EF-11006*



*Fuel water separator 900FG
EF-11007*



*Fuel water separator 900FG (Iron.)
EF-11008*



*Fuel water separator 500FG
EF-11009*



*Fuel water separator 500FG NEW
EF-11010*



*Fuel water separator 600FG
EF-11011*



*81125016058
EF-11012*



*Fuel water separator 300FG
EF-11013*



*Fuel water separator 900FG (Iron)
EF-11014*



*ATT00016
EF-11015*



*Fuel water separator 1000FH with heater
EF-11016*



*Fuel water separator 900FH with heater
EF-11017*



*Fuel water separator 500FH with heater
EF-11018*



*Fuel water separator 500FG with heater
EF-11019*



*Fuel water separator 600FG with heater
EF-11020*



*Fuel water separator 81.12501 6084 with heater
EF-11021*



*Fuel Filter R12P
EF-41001*



*Fuel Filter R12T
EF-41002*



*Fuel Filter R20P
EF-41003*



*Fuel Filter R20T
EF-41004*



*Fuel Filter R60P
EF-41005*



*Fuel Filter R60T.
EF-41006*



*Fuel Filter R90P
EF-41007*



*Fuel Filter R90T
EF-41008*



*Fuel Filter R90-30MB
EF-41009*



*Fuel Filter 0070.131.010
EF-41010*



*Fuel Filter R120P
EF-41011*



*Fuel Filter R120P new version
EF-41012*



*Fuel Filter R120T
EF-41013*



*Fuel Filter R120T version 2
EF-41014*



*Fuel Filter R13T
EF-41015*



*Fuel Filter FD-3375
EF-41016*



*Fuel Filter R60-10-HP
EF-41017*



*Fuel Filter 82005016
EF-41018*



*Fuel Filter R12T with bowl
EF-41019*



*Fuel Filter R13T with bowl
EF-41020*



*Fuel Filter R60P with bowl
EF-41021*



*Fuel Filter R90P with bowl
EF-41022*



*Fuel Filter R90P with bowl.
EF-41023*



*Fuel Filter R120P with bowl
EF-41024*



*Fuel Filter R120P with bowl.
EF-41025*



*Fuel Filter VG1540080211
EF-41026*



*Fuel Filter 140R
EF-41027*



*Fuel Filter 320R
EF-41028*



*Fuel Filter 230R (R20P)
EF-41029*



*Fuel Filter 230R (R20T)
EF-41030*



*Fuel Filter 460R (R60P)
EF-41031*



*Fuel Filter 460R (R60T)
EF-41032*



*Fuel Filter 460R (R60T) with heater
EF-41033*



*Fuel Filter 690R (90P)
EF-41034*



*Fuel Filter 490R (R90P) with heater
EF-41035*



*Fuel Filter 490R (R90P).
EF-41036*



*Fuel Filter 490R (R90T) with heater
EF-41037*



*Fuel Filter 690R (90T)
EF-41038*



*Fuel Filter 4120R (120P)
EF-41039*



*Fuel Filter 4120R (120P).
EF-41040*



*Fuel Filter 4120R (120T) with heater
EF-41041*



*Fuel water separator 140R(R12T)
EA-12002*



*Fuel water separator 140R(R12P)
EA-12003*



*Fuel water separator 230R(R20T)
EA-12004*



*Fuel water separator 230R(R20P)
EA-12005*



*Fuel water separator 660R(R60P)-1
EA-12006*



*Fuel water separator 660R(R60T)-1
EA-12007*



*Fuel water separator 690R(R90P)-1
EA-12008*



*Fuel water separator 690R(R90T)-1
EA-12009*



*Fuel water separator 660R(R60P)-2
EA-12010*



*Fuel water separator 660R(R60T)-2
EA-12011*

Fuel filter-Water Separator

Shanghai East Filters Manufacturer Co., Limited - Leading manufacturer of water separator, fuel filters, fuel water separators, oil water separators and oil filters

Website: <http://www.eastfilters.com/> Email: sales@eastfilters.com



*Fuel water separator 690R(R90P)-2
EA-12012*



*Fuel water separator 690R(R90T)-2
EA-12013*



*Fuel water separator 460R(R60P)
EA-12014*



*Fuel water separator 460R(R60T)
EA-12015*



*Fuel water separator 490R(R90P)
EA-12016*



*Fuel water separator 490R(R90T)
EA-12017*



*Fuel water separator 460R(R60P) with heater
EA-12018*



*Fuel water separator 460R(R60T) with heater
EA-12019*



*Fuel water separator 490R(R90P) with heater
EA-12020*



*Fuel water separator 490R(R90T) with heater
EA-12021*



*Fuel water separator R23401-1284
EA-12022*



*Fuel water separator 8159975
EA-12023*



*Fuel water separator 40853-1/00 1393640
EA-12024*



*Fuel water separator R90-MRT-01
EA-12025*



*Fuel water separator R90-MRT-02
EA-12026*



*Fuel water separator R90-MRT-03
EA-12027*



*Fuel water separator 6120R(R120P)-1
EA-12028*



*Fuel water separator 6120R(R120T)-1
EA-12029*



*Fuel water separator 6120R(R120P)-2
EA-12030*



*Fuel water separator 6120R(R120T)-2
EA-12031*



*Fuel water separator 4120R(R120P)-1
EA-12032*



*Fuel water separator 4120R(R120T)-1
EA-12033*



*Fuel water separator 4120R(R120P)-2
EA-12034*



*Fuel water separator 6120R(R120P)-3
EA-12035*



Fuel water separator 6120R(R120P)-4
EA-12036



Fuel water separator ISUZU 6120-6
EA-12037



Fuel water separator ISUZU 6120-7
EA-12038



Fuel water separator ISUZU 4120-8
EA-12039



Fuel water separator R90-MER-01
EA-12040



Fuel water separator R90-MER-0/D
EA-12041



Fuel water separator 1110474-1
EA-12042



Fuel water separator 1110474-2
EA-12043



Fuel water separator 4120R(R120P) with heater
EA-12044



Fuel water separator 4120R(R120T) with heater
EA-12045



Fuel water separator 7111-296
EA-12067



Fuel water separator RK45MB
EA-12070



Fuel water separator S3227
EA-12071



Fuel water separator 445R
EA-12072



Fuel water separator 445R with pump
EA-12073



Fuel water separator A4570920001KZ
EA-12074



Fuel water separator 8159966
EA-12075



Fuel water separator 0070.131.004
EA-12076



Fuel water separator EA-12077
EA-12077



Fuel water separator 1618385091
EA-12078



Fuel water separator 4160R(160T)
EA-12080



Fuel water separator D00-305-02+A
EA-12081



Fuel water separator FS1003
EA-12082



Fuel water separator FS19816
EA-12083



*Fuel water separator R90-MER-01.
EA-12084*



*Fuel water separator SFC5705
EA-12085*



*Fuel water separator PL270
EA-12086*



*Fuel water separator 420/2 612630080088
EA-12087*



*Fuel water separator PL420
EA-12088*



*Fuel water separator PL420-2
EA-12089*



*Fuel water separator PL420-3
EA-12090*



*Fuel Filter S3208T
EA-41005*



*Fuel Filter S3208T with bowl
EA-41006*



*Fuel Filter R25T
EA-41007*



*Fuel Filter S3213
EA-41008*



*Fuel Filter D638-002-03
EA-41010*



*Fuel Filter RK45-M3
EA-41011*



*Fuel Filter R120-10MB-AQII
EA-41015*



*Fuel Filter GERMANY-R90P
EA-41018*



*Fuel Filter BPTC-E4-LX-01
EA-41025*



*Fuel Filter PFF-5602
EA-41027*



*Fuel Filter 16403 NY000
EA-41029*



*Fuel Filter P.N.2914 8070 00
EA-41030*



*Fuel Filter P.N.2914 8071 00
EA-41031*



*Fuel Filter N/22-S3226FL01-1
EA-41032*



*Fuel Filter 11LB-20310
EA-41033*



*Fuel Filter 1393640
EA-41034*



*Fuel Filter PI-8704643
EA-41035*



Fuel Filter SF8315
EA-41036



Fuel Filter 33231
EA-41037



Fuel Filter 33232
EA-41038



Fuel Filter E1230-4654
EA-41039



Fuel Filter 612630080088
EA-41040



Fuel Filter 612630080205
EA-41041



Fuel Filter 612630080203
EA-41043



Fuel Filter R60S-PHC-C
EA-41044



Fuel Filter VG15400800110
EA-41045



Fuel Filter R160T
EA-41053



Fuel Filter VG1560080012
EA-41054



Fuel Filter 612630010239
EA-41055



Fuel Filter G5800-1105240
EA-41056



Fuel Filter G5800-1105240C
EA-41057



Fuel Filter G5800-1105140A
EA-41058



Fuel Filter G5800-1105140
EA-41059



Fuel Filter S3227
EA-41060



Fuel water separator 0000900212
EA-13001



Fuel water separator 44803-1080
EA-13046



Fuel water separator ME448031080
EA-13047



Fuel water separator EA-13048
EA-13048



Fuel water separator ME039811
EA-13049



Fuel water separator ME091412
EA-13050



Fuel water separator 600-311-9731
EA-13051



Fuel water separator 515
EA-13052



Fuel water separator 31920 66101
EA-13053



Fuel water separator 31925-45100
EA-13054



Fuel water separator DES.NO 5864000
EA-13055



Fuel water separator 141BFS-1
EA-13056



Fuel water separator 141FS-1
EA-13057



Fuel water separator 141BFS-2
EA-13058



Fuel water separator 141FS-2
EA-13059



Fuel water separator 141BFS-3
EA-13060



Fuel water separator 141FS-3
EA-13061



Fuel water separator 151FS
EA-13062



Fuel water separator LYN-EM01
EA-13063



Fuel water separator 0986450695 db0695
EA-13064



Fuel water separator LYN-EM02
EA-13065



Fuel water separator 2656F810
EA-13066



Fuel water separator 0986450695 DB0695
EA-13068



Fuel water separator EA-13069



Fuel water separator STR
EA-13101



Fuel water separator SDW
EA-13102



Fuel water separator ME971608
EA-13103



Fuel water separator 1-132-10170
EA-13104



Fuel water separator A5410920503
EA-13105



Fuel water separator 23100-1070A
EA-13106



Fuel water separator EF101F
EA-13107



Fuel water separator 23300-54040 2L-II
EA-13108



Fuel water separator H70WK02
EA-13109